

## Druckwerkschema / Printhead Layout

Druckwerk / Printhead No. 9434681

Druckbandsatz /  
Printband Set No. **9434682**

	1.	2.	3.	4.	5.	6.	7.	8.
	9378394	9379084	9378399	9379084	9379084	9378399	9379084	9379084
1	1	1	1.	1	1	1.	1	1
2	2	2	2.	2	2	2.	2	2
3	3	3	3.	3	3	3.	3	3
4	4	4	4.	4	4	4.	4	4
5	5	5	5.	5	5	5.	5	5
6	6	6	6.	6	6	6.	6	6
7	7	7	7.	7	7	7.	7	7
8	8	8	8.	8	8	8.	8	8
9	9	9	9.	9	9	9.	9	9
10	κ	0	0.	0	0	0.	0	0
11	SK	-	-.	-	-	-.	-	-
12	Ft	/	/.	/	/	/.	/	/
13								

**5,0**

Drucktypenhöhe /  
Height of Print Type

**2,80**

Bandbreite /  
Width of Band